

Instruction Manual
P2125BA/EN
2014-06

OMEGA TECHNOLOGIES

Cleco[®]

110/120PTHH
Pulse shut-off nutsetter



For additional product information visit our website at:
<https://dotcotool.com/product-category/cleco-tools/cleco-pulse-tools-cleco-air-tools/cleco-h-series-shut-off-model-pistol-grip-pulse-tools-cleco-pulse-tools-cleco-air-tools/>

Notes on this instruction manual

The original language of this instruction manual is German.

This instruction manual

- provides important instructions for safe and effective operation.
- It describes the function and operation of the pulse shut-off nutsetter(hereafter referred to simply as 110/120PTHH).
- It serves as a reference work for technical data, service intervals and spare part orders.
- It points out options.

Secondary information

P2204BA Instruction Manual Oil filling unit

In the text

110/120PTHH stands for all of the designs of the pulse shut-off nutsetter described here.

→ identifies instructions to be followed.

• identifies lists.

<...> identifies an index, see .

In graphics

← identifies movement in a direction.

↓ identifies function and force.

In graphic illustrations

If not absolutely essential, 110/120PTHH (air from bottom) is illustrated.

Model Key

	x	P	T	H	H	x	30	x	
Max. capacity									Output drive
110 – 110 Nm									4 – External square 1/2"
120 – 120 Nm									Q – Quick change chuck 7/16"
Design									Speed
P – Pistol grip									30 – 3,000 rpm
Shutoff									2. Air Inlet
T – Torque controlled shut-off									A – Air from top
									– None
Pulse mechanism									Design
H – Hydraulics									H

Disclaimer:

Apex Tool Group reserves the right to modify, supplement or improve the document or the product without prior announcement. This document may not be reproduced in any way, shape or form, in full or parts thereof, or copied to another natural or machine readable language or to a data carrier, whether electronic, mechanical, optical or otherwise without the express permission of Apex Tool Group.

Contents

1	Safety	5
1.1	Warnings and notes.....	5
1.2	Basic requirements for safe working practices.....	6
1.3	Operator training	6
1.4	Personal protective equipment.....	7
1.5	Designated use	7
1.6	Noise and vibrations.....	7
2	Items supplied	8
3	Product description	8
3.1	Operation and functional elements.....	8
3.2	Options	9
4	Before initial operation	9
4.1	Air supply	9
4.2	Change air inlet: top / bottom (only on 110/120PTHHA)	10
4.3	Connect the tool	10
4.4	Setting up the tool	11
5	Troubleshooting	13
6	Maintenance	15
6.1	Service schedule	15
6.2	Fill reserve oil	16
6.3	Complete oil filling	18
7	Disassembly instructions	21
7.1	Remove motor unit.....	21
7.2	Remove throttle valve.....	23
7.3	Remove pulse unit.....	24
8	Assembly instructions	24
8.1	Install motor unit.....	24
8.2	Install pulse unit.....	28
9	Spare parts	29
9.1	Pistol grip 110/120PTHH.....	30
9.2	Pistol grip 110/120PTHHA... ..	32
9.3	Motor unit	34
9.4	Pulse unit.....	36
9.5	Equipment order list	38
10	Technical data	39
10.1	Dimensions 110/120PTHH... in mm.....	39

10.2	Dimensions 110/120PTHHA... in mm	40
10.3	Performance Data	40
10.4	Ambient conditions	41
11	Service	41
12	Disposal	41

1 Safety

1.1 Warnings and notes

Warning notes are identified by a signal word and a pictogram:

- The signal word describes the severity and the probability of the impending danger.
- The pictogram describes the type of danger.

WARNING!



Potentially hazardous situation for health and safety.

If this warning is not observed, death or serious injury may occur.

CAUTION!



Potentially hazardous situation to health and safety, or risk of material and environmental damage. If this warning is not observed, injuries or damage to materials or the environmental could occur.

NOTE



General notes

include application tips and particularly useful information but no hazard warnings.

1.2 Basic requirements for safe working practices

All instructions must be read carefully. Failure to observe the instructions listed below can result in serious injuries.

CAUTION!

- Work with a maximum working pressure of 700 kPa (measured at the air inlet tube of the tool).
- Before initial operation, check that the suspension bail is properly fastened to the balancer.
- 110/120PTHHA: Before using the air inlet from above, make sure that the pipe plug is correctly fitted in the lower air inlet.
- If you hear unusual noises or vibrations, switch off the tool immediately.
Cut off the air supply immediately.
- Before carrying out repairs, adjusting the torque or replacing screw bits, disconnect the tool from the compressed air line.
- The compressed air line must be depressurized before disconnecting it.
- Never use the air hose to hold, raise or lower the tool.
- Air hoses, the suspension bail and fittings must be regularly checked for damage and wear. Renew as necessary.
- Always carry out assembly according to Chapter 9 Spare parts, page 29.
- Use only accessory parts authorized by Apex Tool Group (see product catalog).
- Adjust the torque using the provided hex wrench only. Never use an angular wrench.
- Only use screw bits for machine-controlled fastening tools.
- Make sure that the screw bits are securely inserted.
- Inspect screw bits for visible damage and cracks.
Renew damaged bits immediately.
- The operation, maintenance and repair conditions set forth in the instruction manual must be observed.
- Follow generally valid and local safety and accident prevention rules.

1.3 Operator training

Users must be given instruction in the correct usage of the tool. The operator must make the Operating Manual accessible to users and make sure that the users have read and understood it. The tool may only be connected, used, serviced and repaired by qualified persons. Repairs to the tool may only be performed by authorized personnel.

1.4 Personal protective equipment



- Wear protective goggles to protect against sprays of metal splinters and fluids.
- Wear gloves to protect against skin irritation in case of direct contact with oil.

Danger of injury by being wound up in and caught by machinery

- Wear a hairnet.
- Wear close-fitting clothing.
- Do not wear jewelry.



Sound level in the area of the user > 80 dB(A), danger of hearing damage

- Wear hearing protection.

1.5 Designated use

The 110/120PTHH is designed exclusively for fastening and releasing threaded fasteners.

- Do not use it as a hammer.
- Do not open it or modify it structurally.
- Do not use it in areas where there is a risk of explosion.

1.6 Noise and vibrations

Sound pressure level L_p in accordance with DIN EN ISO 15744

Idle / clockwise rotation for $n \leq 3,000$ rpm

< 78 dB(A)

Vibration values in accordance with DIN EN ISO 28927-2

Idle / clockwise rotation ahv for $n \leq 3,000$ rpm

< 1.0 m/s²

Pulses ahv 110/120PTHH

< 5.0 m/s²


Pulses ahv 110/120PTHHA

< 5.5 m/s²

Pulses ahv 110/120PTHHA + absorber (on request)

< 2.5 m/s²

With vibration levels ahv > 2.5 m/s², the exposure time is to be reduced. See example




2 Items supplied

Check shipment for transit damage and ensure that all items have been supplied:

- 1 110/120PTHH
- 1 This instruction manual
- 1 Declaration of Conformity
- 1 Hex wrench (WAF 2)

3 Product description

3.1 Operation and functional elements



Item.	Designation
1	Reverse switch
2	Torque adjustment, see Abb. 4-1, page 11
3	Pulse count settings, see 4.4.2 Change pulse count, page 12
4	Air inlet

Item.	Designation
5	Connection for evaluation electronics TVP100
6	Start button
7	Reserve oil, see 6.2 Fill reserve oil, page 16
8	Suspension bail
9	Hex wrench (WAF 2), order no. 935490

3.2 Options

	Order no. 934918 Signal connection kit for evaluation elec- tronics TVP100		Protective sleeve Order No. 937451PT – 110/120PTHH... Order No. 937446PT – 110/120PTHHA...
			Vibration absorber Order No. 935966 – 110/120PTHHA...

4 Before initial operation

4.1 Air supply

Parameter	Data
Air hose	Inner diameter 3/8" (ø 9.5 mm), maximum length 5 m
Air inlet	1/4" NPT, inner diameter ≥ 7.5 mm

- Make sure that the pressure before the pressure regulator is at least 0.5 bar higher than the required inlet air pressure at the tool.
- Keep the inside of the air hose free of residue; clean it if necessary.

Air quality

In accordance with ISO 8573-1, quality class 2.4.3, compressed air must be dry and clean.

Parameter	Data
Working pressure range	400 ... 700 kPa
Max. dew point	+ 10° C

Air preparation units

Our recommendation: air preparation units (filters, regulators, lubricators) should be installed

Device	Explanation
Filter	Retention of particles > 15 micrometers. Removes more than 90% of condensation.

Device	Explanation
Regulator	To attain constant work results, the working pressure must be kept constant for every individual tool.
Lubricator	Compressed air requires a small amount of oil and is orientated to the air consumption of the tool. → Calculate the time (T) between two drops of oil and make the following settings at the lubricator: $T = \frac{60}{F \times L}$ F = Factor for pulse shut-off nutsetter = 4 L = Air consumption of tool at idle m³/min (see performance data for pulse shut-off nutsetter)

Oils according to DIN 51524 / ISO 3498

Order no.	Packaging unit Liter	Name	ARAL	BP	elf	ESSO	INA	Mobil	Klüber	SHELL
933090	2	HL32	Aralub EE 100	Energol HL 32	Polyelis 32 Olna 32	Nuto H 32	Hydraol 32A	D.T.E.Oil Light Vactra Oil Light	Crucolan 32	Molina 32 Molina 22

4.2 Change air inlet: top / bottom (only on 110/120PTHHA)

When delivered, the air inlet is at the BOTTOM and sealed with a screw plug. To change the air supply from top to bottom:

- Remove the air strainer from the air inlet at the TOP (do not discard), see 9.2 Pistol grip 110/120PTHHA..., page 32, Detail X.
- Remove screw plug from BOTTOM. When doing this, counterhold with wrench (WAF 17).
- Seal the air inlet at TOP with screw plug in accordance with specifications.

4.3 Connect the tool


CAUTION!



The air hose can come off by itself and whip around uncontrollably.

- Shut off the compressed air before making the connection.
- Connect the tool to the compressed air line.
Maximum screwing-in torque = 40 Nm. Reaction torque at flat end. Counterhold with wrench (WAF 17).
- Activate compressed air: 620 kPa in anticlockwise rotation.

4.3.1 Testing



- Fully open exhaust air throttle anti-clockwise.
- Check speed at output drive:
Clockwise rotation 3,000 $\pm$ 500 rpm
Anticlockwise rotation 5,500 $\pm$ 500 rpm.

4.4 Setting up the tool

The tool must be configured for the desired rundown.

4.4.1 Setting the torque

CAUTION!




Danger of injury from unintended startup.
Shut off the compressed air before adjusting the torque.

CAUTION!



Danger of injury from rotating hex wrench.
Adjust the torque using the provided hex wrench only. Never use an angular wrench.



Settings example:
Tightening: 120 Nm
Screw M12: 10.9

- Approximately 5 turns of the torque adjustment screw

Abb. 4-1




Abb. 4-2

1. Hold the output drive firmly.
2. Carefully push the hex wrench (WAF 2) through the hole of the pistol grip housing until it reaches the torque adjustment screw ①.
3. Turn the torque adjustment screw and roughly set the required torque, see Abb. 4-1 , page 116.
Total number of turns = 6.
4. Remove hex wrench.
The hole will automatically close after starting.
5. Carry out the rundown.
6. Check the shutoff mechanism worked properly, see 4.4.3 Measuring the torque, page 13.
7. In case of deviations, correct the torque setting and
8. Repeat the rundown.

4.4.2 Change pulse count




Abb. 4-3

Requirement	Measure	
High shut-off accuracy – especially with hard screwed joints. Increase number of pulses per tightening. Recommended number of pulses > 6.	Reduce the speed.	1. Unscrew the threaded pin using the hex wrench (WAF 2). 2. Turn exhaust air throttle ② clockwise.
Shortening the rundown time, particularly for soft joints.	Increase the speed.	1. Unscrew the threaded pin using the hex wrench (WAF 2). 2. Turn exhaust air throttle ② anti-clockwise.

NOTE



A pulse count change may be carried out while the compressed air is activated.
After changing the pulse count, check the screwed torque and correct the setting as necessary, see Abb. 4-2 , page 12.

4.4.3 Measuring the torque

We recommend carrying out a static torque measurement by retightening the screwed joint.

When carrying out a dynamic measurement using a transducer adapter, also carry out a static test on the screwed joint, for example with a torque wrench (electronic).

5 Troubleshooting

Error	Possible causes	Measures and remedies
Tool does not switch off	Torque set too high	→ Reduce the torque setting, see Abb. 4-1 , page 11
	Pulse count set too low	→ Increase pulse count, see 4.4.2 Change pulse count, page 12
	Working pressure < 400 kPa	→ Check the cross section of the hose and coupling: Inner diameter 3/8" (ø 9.5 mm), maximum length 5 m → Increase the working pressure.
	Reverse button is not at the detent	→ Turn the reverse button to the detent
	Excessive transmission damping due to extension and worn socket.	→ Use a shorter or more rigid extension. → Replace the socket
	Insufficient oil in the pulse unit (no pulse build-up)	→ See 6.2 Fill reserve oil, page 16 → If X = 0 (see picture 2), the reserve oil is exhausted and must be refilled to guarantee a controlled process., page 16
	Screen in the air inlet tube / muffler is dirty	→ Clean or replace parts
Insufficient shut-off accuracy	Pulse count too low: <6	→ Increase pulse count, pulse count > 6
	Adapter parts	→ Replace adapter parts → Use extension and socket with guide diameter
	Pressure fluctuations in the air network	→ Use a pressure regulator
Fastening time too long: > 4 seconds	Joint too soft; crush nuts, self-tapping screws	→ Use a pulse nutsetter with higher capacity. Use next tool size. → Use a mechanical screwdriver

Empty side

6 Maintenance

CAUTION!



Danger of injury due to unintentional activation
– before service, disconnect the tool from the compressed air supply.

6.1 Service schedule

Regular service reduces operating faults, repair costs and downtime.

Maintenance interval	Rundowns	Measures
W1	100.000	→ Check the suspension bail for functional safety. → Check the air hose for wear. → Check the square on the output drive for wear. → Check the air inlet for tight fit. → Check the housing of the pulse unit for tight fit. → Check the maximum idling speed. → Check the reserve oil.
W2	500.000	→ Oil change, see 6.3 Complete oil filling, page 18. → Motor service kit, see 3) Part of motor service kit K1, order no. 936282PT, page 31. → Hydraulic service kit, see 3) Part of hydraulic service kit K2, order no. 936035PT, page 37. → Replace muffler, filter.
W3	1,000,000	Check individual parts and replace if necessary → Suspension bail → Throttle valve → Exhaust air throttle → Motor → Pulse unit

This maintenance schedule uses values that are valid for most applications. For a specific maintenance interval, see 6.1.1 Calculating a customer-specific maintenance plan, page 16.

Implement a safety-related maintenance program that takes the local regulations for repair and maintenance for all operating phases of the tool into account.

6.1.1 Calculating a customer-specific maintenance plan

A service interval **W(1,2,3)** depends on the following factors:

Factor	Value assumed in 6.1, "Maintenance plan"	Description
V	V1 = 100,000 V2 = 500,000 V3 = 1,000,000	Number of rundowns after which a maintenance measure is prescribed by Apex Tool Group.
T1	1.8 seconds	Specific rundown time, measured in life and endurance tests.
T2	2 seconds	Actual rundown time, depending on the hardness of the joint.
S	1; 2; 3	Number of shifts per day.
VS	750	Number of rundowns per shift.

T2, S and **VS** are variable factors and can differ depending on the specific application.

Example for service interval W2:



After 500,000 rundowns (V),
a specific rundown time of 1.8 seconds (T1)
with an actual fastening time of 3 seconds (soft joint) and
3 completed shifts per day and 750 rundowns per shift:

$$W(1, 2, 3) = \frac{V \times T_1}{T_2 \times S \times VS} \quad W2 = \frac{500000 \times 1,8}{2 \times 3 \times 750} = 200 \text{ Tage}$$

You have to carry out the maintenance measures marked W2 after an operating time of 200 days.

6.2 Fill reserve oil

If **X = 0** (see picture 2), the reserve oil is exhausted and must be refilled to guarantee a controlled process.


1

→ Remove pulse unit.




2

→ Remove set bolt and ball.




3


→ Align both ends as shown in the picture (internal equalization hole is opened).

**4**

→ To avoid air pockets, fill the filling hole full of oil.

**5**

→ Position the injector so that it has a sealing effect and add reserve oil until distance **X** for spacer **<B2>** is present.
 → Maintain distance **X** and secure with **<B2>**.
 → Refit set bolt and ball.
 → Remove **<B2>**.




6.3 Complete oil filling

If no more pulses are generated, or if the pulse unit has been removed and refitted, the pulse unit must be completely refilled with oil:

Oil order No. 925715, ESSO-UNIVIS HVI26, approx. 2 liters, temperature $20 \pm 5^\circ\text{C}$


1

→ Remove set bolt and ball



2


→ Align both ends of the pulse unit as shown in the picture (internal equalization hole is opened)



3

→ Use adapter ① to connect pulse unit to the quick disconnect coupling.

→ Close shutoff valve ②.



4

→ Set the working pressure to approx. 500 kPa.

→ Slowly open the shut-off valve all the way until the gauge shows a negative pressure of $<10\text{ mbar}$ (-1 bar).

→ Wait approx. 2 minutes until the number of vacuum bubbles has reduced significantly.


→ Slowly close the shut-off valve. The gauge shows atmospheric pressure again. Missing oil will be pressed back into the pulse unit.

→ If necessary, repeat the last 3 rundown steps until bubbles are reduced practically to zero.




5

- Uncouple the pulse unit and unscrew the adapter.
- To avoid air pockets, fill the filling hole full of oil.

**6**

- Position the injector so that it has a sealing effect and add reserve oil until distance **X** for spacer **<B2>** is achieved.
- Maintain distance **X** and secure with **<B2>**.
- Refit set bolt and ball.
- Remove **<B2>**.




- Small air bubbles that become visible due to the high pressure during filling do not mean that the pulse unit is leaking. The filling process is not impaired.
- If a flow of large rapid bubbles appear and continue to be produced and the pressure drops, there is a leak inside of the pulse unit.

Empty side


7 Disassembly instructions

<...> Please refer to 9 Spare parts, page 29 und 9 Spare parts, page 29


7.1 Remove motor unit




7.1.1 Remove actuating ring




7.1.2 Remove shut-off





7.2 Remove throttle valve



7.3 Remove pulse unit




Abb. 7-1

CAUTION!



Skin irritation in case of direct contact with oil.
Wear protective gloves.

CAUTION!



Hydraulic blade is under spring pressure!
Wear protective goggles.

NOTE



Permitted only if filling is guaranteed with oil filling device, see 6.2 Fill reserve oil, page 16. Pulse unit must have cooled down to room temperature.

8 Assembly instructions

<...> Please refer to 9 Spare parts, page 29 und 9 Spare parts, page 29

8.1 Install motor unit

CAUTION!




- Only perform installation in accordance with exploded drawing, see 9 Spare parts, page 29. Incorrect installation can lead to uncontrolled reactions, e.g. unexpected start-up or parts being hurled out.
- Tighten all screwed joints of the tool carefully, according to the specifications.

NOTE




To prevent damage, lubricate the gaskets and O-rings using grease (order no. 914392) before assembly.


8.1.1 Install rotor cover



1. Press <59> in with <C4>, see X.




2. **Examine Y** with thickness gage. If dimension > Y, step 1 with support <C5>, <C6>, <C7> repeat.




Press <61> in with <C8>.

8.1.2 Install shut-off



8.1.3 Install actuating ring




8.2 Install pulse unit

NOTE



To prevent damage, lubricate the gaskets and O-rings using grease (order no. 914392) before assembly.

8.2.1 Assembling the hydraulic blades



9 Spare parts

NOTE




Only Cleco original spare parts should ever be used. Using other parts could lead to inferior performance and increased maintenance requirements. If non-original spare parts are installed, the tool manufacturer is entitled to declare all warranty obligations for null and void.

We would be glad to prepare a special quote for you for spare and wear parts.
Please give the following data:

- Tool model
- Number of tools
- Number of rundowns per day or per shift
- Shut-off torque
- Fastening time per rundown

9.1 Pistol grip 110/120PTHH...



Index	1)	2)	3)	Description	4)
1	937427PT	1		pistol grip housing asm.	
3	935720	1	K1	muffler	
4	935434	1		exhaust air throttle	
5	922660	1	K1	o-ring	16,X1,5
6	935437	1		air inlet	
7	905031	1	K1	screen	
8	905599	1	K1	circlip	11,X1, IR
9	S905998	1	K1	set bolt	M 4X4
10	935613	1		reverse button	
11	931792	1		countersunk screw	M 3X 14
12	935442	1		suspension bail	
13	935482	1	K1	compression spring	0,5 X 6,X 23,8
14	539188	1	K1	o-ring	9,X1,
15	935441	1		piston	
16	504970	1	K1	o-ring	7,65X1,78
17	935440	1		control push rod	
18	912150	1	K1	o-ring	12,X1,
19	935439	1		plug	
20	905086	1	K1	o-ring	4,X1,
21	935446	1		push-button	
22	911315	1	K1	ball	3,000MM
23	903764	1	K1	o-ring	41, X2
25	916772	1	K1	needle roller	3,X9,8
26	935645	1	K1	circlip	46, X1,75 IR
100	934917	1		fastening plug	


1)Order no.

2)Quantity

3) Part of motor service kit K1, order no. 936282PT

4)Dimensions

9.2 Pistol grip 110/120PTHHA...



Index	1)	2)	3)	Description	4)
1	937436PT	1		pistol grip housing asm.	
3	935720	1	K1	muffler	
4	935434	1		exhaust air throttle	
5	922660	1	K1	o-ring	16,X1,5
6	935437	1		air inlet	
7	905031	1	K1	screen	
8	905599	1	K1	circlip	11,X1, IR
9	S905998	1	K1	set bolt	M 4X4
10	935613	1		reverse button	
11	931792	1		countersunk screw	M 3X 14
12	935442	1		suspension bail	
13	935482	1	K1	compression spring	0,5 X 6,X 23,8
14	539188	1	K1	o-ring	9,X1,
15	935441	1		piston	
16	504970	1	K1	o-ring	7,65X1,78
17	935440	1		control push rod	
18	912150	1	K1	o-ring	12,X1,
19	935439	1		plug	
20	905086	1	K1	o-ring	4,X1,
21	935446	1		push-button	
22	911315	1	K1	ball	3,000MM
23	903764	1	K1	o-ring	41, X2
25	916772	1	K1	needle roller	3,X9,8
26	935645	1	K1	circlip	46, X1,75 IR
27	935727	1		air strainer	
28	931771	1		screwed plug	1/4 NPT
100	934917	1		fastening plug	


1)Order no.

2)Quantity

3) Part of motor service kit K1, order no. 936282PT

4)Dimensions

9.3 Motor unit



Index	1)	2)	3)	Description	4)
29	936256	1		motor unit	
30	935479	1	K1	washer	7,1 X 2,4 X 1,5
31	902862	1	K1	retaining ring	10,X1, AR
32	936240PT	1		actuating ring	
33	935405	3	K1	ball	4,76MM (3/16")
34	935464	1	K1	ball sleeve 3,5	Ø6 × 3,5MM
35	937411PT	1		Throttle washer	
36	936677PT	1	K1	compression spring	0,9 X23,1 X21,6
40	936258	1		torque adjustment screw asm.	
44	936236	1		shut-off piston	
45	926570	1	K1	o-ring	10,X1,
47	936699PT	1		air distributor	
48	917793	3	K1	ball	2,500MM
49	936242	3	K1	ball	2,500MM
50	936237	1		sleeve	
51	942066PT	1	K1	compression spring	0,4X 5,6 X 19,6
52	917794	1	K1	ball	4,500MM
53	935921	1	K1	compression spring	0,8 X 3,5 X 25,1
54	936243	1	K1	ball bearing	12,X 24,X 6,
55	936235	1		rotor cover	
56	935609	1		rotor cylinder	
58	935623	7	K1	blade	L40,01D1,7 H 9,5
59	936264PT	1		rotor	
60	935621	1		rotor cover	
61	915832	1	K1	ball bearing	17, X 30, X 7,
62	936266PT	1	K1	o-ring	08,X1,65
63	936689PT	1		Ball retainer	
64	058100PT	9	K1	ball	4,762
65	936241	1	K1	compression spring	0,8 X15, X 20,
66	936255	1		washer	
67	926570	1	K1	o-ring	10,X1,
68	935722	7		plug	
69	937413PT	1	K1	washer	3,2 X 4,7 X 0,5


1)Order no.

2)Quantity

3) Part of motor service kit K1, order no. 936282PT

4)Dimensions

9.4 Pulse unit



Index	1)	2)	3)	Description	4)
84	*	1		pulse unit	
85	936032	1	K2	circlip	29 X1,5 AR
86	936033	1	K2	shim ring	30, X 42, X 0,5
87	505719	1	K2	o-ring	29,87X1,78
88	936191	1		equalizing piston	
89	412895	1	K2	o-ring	37,82X1,78
90	936196	1	K2	equalizing washer	39 X 29 X 0,41
91	936193	1		hydraulic cylinder	
92	916772	1		needle roller	3, X9,8
93	*	1		hydraulic rotor asm.	
94	935631	2	K2	compression spring	0,36 X 2,5 X 26,2
95	935916	1		control blade asm.	
96	935726	2	K2	compression spring	0,45X 2,8 X 48,6
97	935915	2		hydraulic blade	
98	935918	1		control blade asm.	
99	935612	1		control disc	
100	917793	8	K2	ball	2,500MM
101	935608	1		bearing ring	
102	911315	1	K2	ball	3,000MM
103	919140	1	K2	set bolt	M4X5
104	S909126	1	K2	o-ring	20,X2,
105	935646	1	K2	o-ring	38,X1,5
106	902106	1	K2	retaining ring	33,X1,2IR
107	935633	1		washer	25,0 X 31,8 X 1,0
108	921414	1	K2	ball bearing	20, X 32, X 7
109	935647	1	K2	o-ring	52,X1,5
110	937405PT	1		housing	
111	933818	1	K2	retaining ring	20,X1,2 AR
112	914433	1		pin	
113	9D6481	1		compression spring	0,3 X 3,2 X 9,2
114	26989PT	1		plug	
115	935651	1	K2	retaining ring	18, X1,2 AR
116	*	1	K2	ball	6,000
117	*	1		sleeve	
118	*	1	K2	compression spring	1,2 X 22, X 33,4
119	*	1		ring	
120	*	1	K2	retaining ring	18, X1,2 AR
121	935725	1	K2	supporting ring	
122	935644	1		ring	

1)Order no.

2)Quantity

3) Part of hydraulic service kit K2, order no. 936035PT

4)Dimensions

Order no.		<84>	<93>	<116>	<117>	<118>	<119>	<120>
120PTHH304	■	936048	935910	—	—	—	—	—
120PTHHA304								
110PTHH30Q	○	936049	935963	903231	935634	935648	935649	935651
110PTHHA30Q								

9.5 Equipment order list

Index	1)	Description
A	928478	Oil filling device
	A1 928483	Oil filling unit
	A2 935718	Joining piece cpl.
B	936695PT	Reserve oil filling set
	B1 936690PT	Oil syringe asm.
	B2 937412PT	Spacer
C	938579PT	Assembly/Disassembly motor unit
	C1 933486	Support
	C2 933483	Semi-monocoque pair
	C3 933480	Punch
	C4 938573PT	Support 0,02 mm
	C5 938574PT	Support 0,03 mm
	C6 938575PT	Support 0,04 mm
	C7 938576PT	Support 0,05 mm
	C8 933489	Punch
	C9 938577PT	Support
D	938504	Socket wrench
E	933498	Assembling the actuating ring
F	938531	Assembly hydraulic blade/control blade
	F1 938533	sleeve
	F2 938532	awl
G	933375	fixture for trigger valve
H	938597PT	Assembling the shutoff
J	938596PT	Assembling the throttle washer
K	938598PT	Assembling the O-ring

1)Order no.

10 Technical data

10.1 Dimensions 110/120PTHH... in mm





Abb. 10-1

10.2 Dimensions 110/120PTHHA... in mm



10.3 Performance Data

Order no.	Recommended torque range		Idling speed rpm	 8.8 mm	 lbs. (kg)	Air consumption	
	min.	max.				ft ³ /min (m ³ /min)	Pulses
120PTHH304 110PTHH30Q	55.3 (75)	88.5 (120) 81.1 (110)	5,500 Anticlockwise 3,000 Clockwise	M12	3.75 1.70	7.06 (0.20)	19.42 (0.55)
120PTHHA304 110PTHHA30Q		88.5 (120) 81.1 (110)			3.86 1.75		

10.4 Ambient conditions

Storage temperature	-25...+60 °C
Working temperature	+5...+40 °C
Permissible relative humidity	25...90%, non-condensing

11 Service

NOTE



In the event of repairs, send the complete 110/120PTHH to Apex Tool Group! Repairs may only be carried out by authorized personnel. Opening the tool will invalidate the warranty.

12 Disposal

CAUTION!



Injuries and environmental damage from improper disposal.

The components and auxiliary materials of a machine incorporate risks to health and the environment.

- Catch auxiliary materials (oils, greases) when drained and dispose of them properly.
- Separate the machine parts by material and dispose of them properly.
- Separate the components of the packing and dispose of them by segregating them clearly.
- Wear suitable protective clothing at the time of disposal.
- Follow the general prevailing disposal guidelines.
- Follow the locally applicable regulations.

POWER TOOLS SALES & SERVICE CENTERS

Please note that all locations may not service all products.

Contact the nearest Apex Tool Group Sales & Service Center for the appropriate facility to handle your service requirements.

 Sales Center

 Service Center

NORTH AMERICA | SOUTH AMERICA

Detroit, Michigan

Apex Tool Group
2630 Superior Court
Auburn Hills, MI 48236
Phone: +1 (248) 393-5640
Fax: +1 (248) 391-6295

Lexington, South Carolina

Apex Tool Group
670 Industrial Drive
Lexington, SC 29072
Phone: +1 (800) 845-5629
Phone: +1 (919) 387-0099
Fax: +1 (803) 358-7681

Louisville, Kentucky

Apex Tool Group
1000 Glengarry Drive
Suite 150
Fairdale, KY 40118
Phone: +1 (502) 708-3400
apexpowertools.com/service

Canada

Apex Tool Canada, Ltd.
7631 Bath Road
Mississauga, Ontario L4T 3T1
Canada
Phone: (866) 691-6212
Fax: (905) 673-4400

Mexico

Apex Tool Group
Manufacturing México
S. de R.L. de C.V.
Vialidad El Pueblito #103
Parque Industrial Querétaro
Querétaro, QRO 76220
Mexico
Phone: +52 (442) 211 3800
Fax: +52 (800) 685 5560

Brazil

Apex Tool Group
Ind. Com. Ferram, Ltda.
Av. Liberdade, 4055
Zona Industrial Iporanga
Sorocaba, São Paulo
CEP# 18087-170
Brazil
Phone: +55 15 3238 3820
Fax: +55 15 3238 3938

EUROPE | MIDDLE EAST | AFRICA

England

Apex Tool Group GmbH
C/O Spline Gauges
Piccadilly, Tamworth
Staffordshire B78 2ER
United Kingdom
Phone: +44 1827 8727 71
Fax: +44 1827 8741 28

France

Apex Tool Group S.A.S.
25 rue Maurice Chevalier
B.P. 28
77831 Ozoir-La-Ferrière
Cedex, France
Phone: +33 1 64 43 22 00
Fax: +33 1 64 43 17 17

Germany

Apex Tool Group GmbH
Industriestraße 1
73463 Westhausen
Germany
Phone: +49 (0) 73 63 81 0
Fax: +49 (0) 73 63 81 222

Hungary

Apex Tool Group
Hungária Kft.
Platánfa u. 2
9027 Győr
Hungary
Phone: +36 96 66 1383
Fax: +36 96 66 1135

ASIA PACIFIC

Australia

Apex Tool Group
519 Nurigong Street, Albury
NSW 2640
Australia
Phone: +61 2 6058 0300

China

Apex Power Tool Trading
(Shanghai) Co., Ltd
2nd Floor, Area C
177 Bi Bo Road
Pu Dong New Area, Shanghai
China 201203 P.R.C.
Phone: +86 21 60880320
Fax: +86 21 60880298

India

Apex Power Tools India
Private Limited
Gala No. 1, Plot No. 5
S. No. 234, 235 & 245
Indialand Global
Industrial Park
Taluka-Mulsi, Phase I
Hinjawadi, Pune 411057
Maharashtra, India
Phone: +91 020 66761111

Japan

Apex Tool Group Japan
Korin-Kaikan 5F,
3-6-23 Shibakoen, Minato-Ku,
Tokyo 105-0011, JAPAN
Phone: +81-3-6450-1840
Fax: +81-3-6450-1841

Korea

Apex Tool Group Korea
#1503, Hibrand Living Bldg.,
215 Yangjae-dong,
Seocho-gu, Seoul 137-924,
Korea
Phone: +82-2-2155-0250
Fax: +82-2-2155-0252

Apex Tool Group, LLC

1000 Lufkin Road
Apex, NC 27539
Phone: +1 (919) 387-0099
Fax: +1 (919) 387-2614
www.apexpowertools.com

