

Parts Manual

45-8198

PL30-12R05

04/20/2011



DOTCO[®]

12R05 Series
Inline Grinder



12	R	05	00	-	XX	XX
----	---	----	----	---	----	----

Terminations

36 = 300 Series Collet - 1/4" (#308) standard included

45 = Universal Collet - 1/4" (#7808) standard included

Optional Collet (use if ordering non-standard collet option)

Termination 36 Options

03 = 3/64" (#301)

05 = 5/64" (#302)

06 = 3/32" (#303)

08 = 1/8" (#304)

10 = 5/32" (#305)

12 = 3/16" (#306)

14 = 7/32" (#307)

M6 = 6mm (#310)

Termination 45 Options

08 = 1/8" (#7809)

12 = 3/16" (#7812)

M3 = 3mm (#7810)


M6 = 6mm (#7811)

For additional product information visit our website at:

<https://dotcotool.com/product-category/dotco-air-tools/dotco-grinders/dotco-inline-grinders/dotco-12-05-series-inline-grinders/>

DOTCO 12R05 Small Wheel Grinders

"A"



DOTCO

12R05 Small Wheel Grinders

PL30-12R05
11/10/2008

Illustration, Abbildung, Illustration, Ilustración, Illustrazione "A"

Ref	Number	#	X	EN	DE	FR	ES	IT
				Description	Benennung	Designation	Descripción	Descrizione
1	1252	3	9	O-Ring	O-Ring	Joint torique	Anillo "O"	Anello ad O
2	1009385	1	3	Screen	Bildschirm	Ecran	Criba	Schermo
3	1011699	1		Valve Asm.	Ventil	Soupape	Válvula	Valvola
4	1011700	1	1	Dial	Skalenscheibe	Cadran	Cara	Faccia
5	1011697	1	2	Set Screw	Stellschraube	Vis de pression	Tornillo fijador	Vite di arresto
6	01-1801	1		Housing	Gehäuse	Corps	Caja	Corpo
7	1011701	1		Pin	Stift	Goupille cylindrique	Pasador	Spina
8	1011703	1		Spacer	Distanzstück	Entretoise	Espaciador	Distanziale
9	1013829	1	1	Rotor Screw	Schraube	Vis	Tornillo	Vite
10	505	2	4	Ball Bearing	Kugellager	Roulement à billes	Cojinete de bolas	Cuscinetto a sfera
11	1011704	1		Rear Plate	Hintere Platte	Plaque arrière	Placa posterior	Piattello posteriore
12	01-1809	1	3	O-Ring	O-Ring	Joint torique	Anillo "O"	Anello ad O
13	1110242	1		Cylinder	Zylinder	Cylindre	Cilindro	Cilindro
14	1110238	3	6	Rotor Blade	Rotorblatt	Palette	Alabe del rotor	Paletta del rotore
15	01-1805	1		Rotor	Rotor	Rotor	El rotor	Il rotore
16	01-1803	1		Spacer	Distanzstück	Entretoise	Espaciador	Distanziale
17	01-1814	1		Front Plate	Vorderplatte	Plaque de devanture	Placa frontal	Piattello anteriore
18	2965	1	3	O-Ring	O-Ring	Joint torique	Anillo "O"	Anello ad O
19	01-1810	1		Deflector	Ablenker	défecteur	deflector	deflettore
20	1011713	1		Retainer	Haltevorrichtung	Bague d'arrêt	Retén	Fermo
21	Table A	1		Chuck Body	Futter Körper	Corps de trou	Bote el Cuerpo	Il Corpo di ciottolo
22	Table A	1		Collet	Futter	Douille de serrage	Boquilla	Bussola di chiusura
23	1053	1		Nosepiece	Kopfstück	Tuyère	Tobera	Naso
24	1058	1		Cap	Kappe	Chapeau	Tapa	Cappello
25	1011116	1		Collet Nut	Hülse Mutter	Noix de douille	La Nuez de Collet	Incastonare la Noce
26	01-1802	1		Collet Guard	Schutzvorrichtung	Protection	Guarda	Protezione
27	1011715	1		Service Wrench	Schraubenschlüssel	Clé plate	La llave	La chiave
--	14-1307	1		Hose	Schlauch	Tuyau	Manguera	Tubo
--	14-0807	1		Wrench (7/16")	Schraubenschlüssel	Clé plate	La llave	La chiave
--	14-0811	1		Wrench (11/16")	Schraubenschlüssel	Clé plate	La llave	La chiave

(#) Quantity / Stückzahl / Quantité / Cantidad / Quantità

(X) Recommended Spare Parts / Kennzeichnet empfohlene / Identifica un particolare di ricambio raccomandato / Designa el repuesto recomendado / Indique la pièce de rechange conseillée.

Table, Tabelle, Tableau, Tabla, Tabella "A"

Ref.	Description	#	12R0500-36	#	12R0500-45
21	Chuck Body	1	01-1824	1	01-1804
22	Collet	1	308	1	7808

Sales & Service Centers

Note: All locations may not service all products. Please contact the nearest Sales & Service Center for the appropriate facility to handle your service requirements.

Dallas, TX
**Apex Tool Group
Sales & Service Center**
1470 Post & Paddock
Grand Prairie, TX 75050
Tel: 972-641-9563
Fax: 972-641-9674

Detroit, MI
**Apex Tool Group
Sales & Service Center**
2630 Superior Court
Auburn Hills, MI 48326
Tel: 248-391-3700
Fax: 248-391-7824

Houston, TX
**Apex Tool Group
Sales & Service Center**
6550 West Sam Houston
Parkway North, Suite 200
Houston, TX 77041
Tel: 713-849-2364
Fax: 713-849-2047

Lexington, SC
Apex Tool Group
670 Industrial Drive
Lexington, SC 29072
Tel: 800-845-5629
Tel: 803-951-7544
Fax: 803-358-7681

Los Angeles, CA
**Apex Tool Group
Sales & Service Center**
15503 Blackburn Avenue
Norwalk, CA 90650
Tel: 562-623-4457
Fax: 562-802-1718

Seattle, WA
**Apex Tool Group
Sales & Service Center**
2865 152nd Avenue N.E.
Redmond, WA 98052
Tel: 425-497-0476
Fax: 425-497-0496

York, PA
**Apex Tool Group
Sales & Service Center**
3990 East Market Street
York, PA 17402
Tel: 717-755-2933
Fax: 717-757-5063

Canada
**Apex Tool Group
Sales & Service Center**
5925 McLaughlin Road
Mississauga, Ont. L5R 1B8
Canada
Tel: 905-501-4785
Fax: 905-501-4786

Germany
Cooper Power Tools
GmbH & Co. OHG
a company of
Apex Tool Group, LLC
Industriestraße 1
73463 Westhausen
Germany
Tel: +49 (0) 73 63 81 0
Fax: +49 (0) 73 63 81 222

England
Cooper Power Tools
GmbH & Co. OHG
a company of
Apex Tool Group, LLC
C/O Spline Gauges
Piccadilly, Tamworth
Staffordshire B78 2ER
United Kingdom
Tel: +44 1827 8741 28
Fax: +44 1827 8741 28

France
Cooper Power Tools SAS
a company of
Apex Tool Group, LLC
25 rue Maurice Chevalier
77330 Ozoir-La-Ferrière
France
Tel: +33 1 6443 2200
Fax: +33 1 6443 1717

China
Cooper (China) Co., Ltd.
a company of
Apex Tool Group, LLC
955 Sheng Li Road,
Heqing Pudong, Shanghai
China 201201
Tel: +86-21-28994176
Fax: +86-21-51118446

Mexico
Cooper Tools
de México S.A. de C.V.
a company of
Apex Tool Group, LLC
Vialidad El Pueblito #103
Parque Industrial Querétaro
Querétaro, QRO 76220
Mexico
Tel: +52 (442) 211-3800
Fax: +52 (442) 103-0443

Brazil
Cooper Tools Industrial Ltda.
a company of
Apex Tool Group, LLC
Av. Liberdade, 4055
Zona Industrial - Iporanga
SP Brazil
Tel: +55 15 2383929
Fax: +55 15 2383260

Hungary
Cooper Tools Hungaria Kft.
a company of
Apex Tool Group, LLC
Berkenyefa sor 7
Pf: 640
9027 Győr
Hungary
Tel: +36 96 66 1383
Fax: +36 96 66 1135

Apex Tool Group, LLC
1000 Lufkin Road
Apex, NC 27539
Phone: 919-387-0099
Fax: 919-387-2614
www.apextoolgroup.com

DOTCO®